

Installation Instruction

2800095-b


These instructions are written for qualified and experienced personnel. Please study them carefully before starting any work. Any liability or responsibility for the results of improper or unsafe installation practices is disclaimed. Please respect valid environmental regulations for assembly and waste disposal. Always make sure to use appropriate personal protection!

RFS Surge Arrestors provide reliable protection against dangerous surge signals on coaxial lines. This includes all kinds of interference e.g. resistive, magnetic field and electric field coupling caused by lightning strikes, switching and other natural or man made electrical effects.

Best protection is achieved if the protector is properly integrated in the bonding/grounding system of the electronic equipment following the lightning protection zone principle of IEC 61312-1.

Bulkhead installation Hex nut Lock washer Flat seal Hole pattern 7-16

The protection zone principle favors the feed through installation In a conductive bulkhead which is simultaneously the boarder to the higher protection zone containing the equipment to be protected. It is recommended to place a surge arrestor outside (see sketch).





Installation Instruction

2800095-b

Grounding System

If it is not possible to install the surge arrestor in a bulkhead assembly the protector should be connected to the bonding facility by a sufficiently sized grounding wire (16mm² / AWG 6 min) as directly as possible. Alternatively the arrestor can also be directly attached to a suitable grounding bar positioned across the cable tray.

Grounding Bar

